




# IR-EMTR-F-1-35 IR-EMTR-F-2-35

## INFRARED EMITTER Information and Installation Guide

### A. : Description


1. Round shape, with elegant & compact size
2. Infrared is built in transparent housing
3. With 7 feet cable length
4. With 3.5mm mono standard plug
5. With self-adhesive tape for quick and easy fixing on any hard, clean & dry surface

### B.:Diagram




### C.: Installation

#### Standard installation




Attach IR emitter at inside of shelf

1. IR emitter (flat side) attached directly to IR sensor window
2. More reliable activated
3. Looks nice



1. Attach IR emitter on above or below of the IR window
2. Less reliable activated

#### Cabinet With door Installation



1. IR emitter is attached to rack door, round shape side facing the IR window
2. Less reliable activated

### D.: Note:

1. Make sure mounting surface must be clean and dry for fixed well
2. Can not be connecting IR emitter directly to power supplies or battery